

User Instructions CMOD 70 Spreader Frame

The CMOD Spreader Frame is modular in span and every frame consists of 4 Corner Units, with intermediate Struts that can be bolted into the assembly to achieve different spans. CMOD 70 has an assembled span ranging from 1m by 1m to 12m by 12m and all spans inbetween.






Fig. 1 – Typical CMOD Spreader Frame Assembly
 β = Sling to vertical angle (STV)



Strut



Corner Unit




Table 1 – Component List

Part Ref.	Description	Weight/item
P1	Corner Unit (length 0.5m each)	180kg
P2	4.0m Strut	240kg
P3	2.0m Strut	136kg
P4	1.0m Strut	85kg
P5	0.5m Strut	61kg
P6	42.5t Shackle	29kg
P7	35t Shackle	20kg
P8	M20 x 65, Grade 8.8, HT Bolts, Nuts & Washers	

CMOD 70 Frame Specification

- Rated at a maximum of 80 tonnes SWL. Please see **Table 2** for SWL at specific spans.
- ‘Sling to Vertical’ angle, β , 45 degrees or less.
- Corner Units are rated at 20 tonnes each (80 tonnes combined capacity).
- **Bolt tightening torque: 150Nm.** Spanner size required: 30mm.
- Recommended additional equipment: Torque Wrench, Podger Spanner and Ring Spanner.

WARNING!

- Personnel using this system should be suitably trained, competent and have a clear understanding of Safe Slings procedures.
- The use of Modulift equipment must be in accordance with the procedures laid down in ‘Lifting Operations and Lifting Equipment Regulations 1998’ (LOLER).
- **Never exceed stated SWL** – Adhere to SWL in **Table 2** for particular sling angle used.
- **The top sling length is critical to the safe use of the spreader** – Ensure you refer to the correct table.

User Instructions CMOD 70 Spreader Frame

WARNING!

- Do not under any circumstances hang load(s) from the tube or flanges – the Spreader Frame is designed for compression – not bending.
- Ensure that the top Shackle contacts the bow of the corner plate 'bow-to-bow'.
- The CMOD system is designed in accordance with BS EN13155: Cranes, Safety, Non- fixed Load Lifting Attachments.
- **Max number of Struts allowed in assembly: 5 per side**
- **Assemble longer Struts in the centre of the configuration**
- **Sling angle is crucial to safe use of frame.**
- **The top sling must be positioned centrally in the Shackle pin to ensure even loading. Contact your Modulift supplier for supply of loose spacers where required.**

Do's & Don'ts

- Do ensure that the frame is only loaded at the Corner Units and they are all equally loaded.
- Do ensure enough clearance between frame and the load to prevent the load hitting the frame. Any collision could cause failure of the frame.
- Do not undertake a lift without the correct use of appropriate top slings.
- Do not hang any loads from the Strut tube or flanges.
- Do not exceed the stated SWL for your span.
- Do not rig the lower slings more than 6° from vertical.

Assembly Procedure

- Check the ID plates on each Modulift component to ensure the correct size is used.
- Lay out the Struts and Corner Units in the correct configuration.
- Check that all flanges are clear from debris, sand etc. before connection.
- Bolt the components together* using bolts, nuts & washers provided. Tighten the bolts to torque as shown overleaf.
- Loop the top Shackles through the bows of the Corner Units so they contact 'bow-to-bow'. The eye of the top slings can then be passed through the jaws of the Shackles and the pins replaced.
- Loop the bottom Shackles through the eyes of the drop slings and connect to the bottom of the Corner Unit with the Shackle pin.
- Attach the lower slings to the load to be lifted.
- The assembled Spreader Frame and lifting rig must be thoroughly checked by a competent person prior to lifting.

*The use of a Podger Spanner will aid in assembly by helping to align the bolt holes by forcing it through.



Table 2 – Load v Span

First pick the span required for your frame (e.g. 2m x 5m) and the Sling Angle (we recommend 30° STV where possible), then check the SWL via the appropriate table. Read the table by locating the lower span on the y axis of the chart and the larger on the x. The cell which you are referred to, will indicate the SWL for your chosen span. If your exact span is not noted in the table, then please round up or down to the values that will give you the lowest SWL (to ensure no overloads are applied). Please contact us for confirmation on your SWL if required. SWL given in tonnes.

CMOD 70: SWL / tonnes @ 30° STV

12												63
11											70	60
10										80	70	58
9									80	80	70	55
8								80	80	80	67	53
7							80	80	80	70	65	51
6						80	80	80	70	60	62	49
5					80	80	80	80	70	60	60	47
4				80	80	80	80	80	70	60	58	46
3			80	80	80	80	80	80	70	60	56	45
2		80	80	80	80	80	80	70	70	60	55	44
1	80	80	80	80	80	80	80	70	70	60	54	44
Span (m)	1	2	3	4	5	6	7	8	9	10	11	12

CMOD 70: SWL / tonnes @ 45° STV

12												36
11											40	34
10										40	40	33
9									46	40	40	31
8								57	46	40	38	30
7							60	57	46	40	37	29
6						60	60	57	40	34	35	28
5					60	60	60	50	40	34	34	27
4				60	60	60	60	50	40	34	33	26
3			60	60	60	60	60	50	40	34	32	26
2		60	60	60	60	60	60	50	40	34	31	25
1	60	60	60	60	60	60	60	50	40	34	31	24
Span (m)	1	2	3	4	5	6	7	8	9	10	11	12